



Small repair instructions

- Find out where the boat is loosing air by going over the suspected area with soapy water
- Mark the area
- Remove all the soap from the repair area
- Clean and buff the repair area
- Buff the repair patch also
- Apply glue to the repair patch and the area to be repaired 2 times and allow between both applications 5 – 10 minutes drying time
- Apply the repair patch to the damaged area
- Apply pressure to the patch, rubbing it with a heavy object
- After 2 hours the boat may be pumped full of air. Do not fill to full pressure

All large repairs should be made by a professional repair workshop for rubber boats, or returned to Spreu Boote.

Spreu Boote
Lennep Straße 33
D- 42289 Wuppertal
Telefon: +49 (0)202 / 62 91 50
Fax: +49 (0)202 / 622549
E-Mail: info@spreu-boote.de
www.spreu-boote.de